
2.4G Touch Remote **Control Instructions**



1.Brief:

RBX series (RB1, RB2, RB3, RB4) and RCX series (RC1, RC2, RC3, RC4) are 2.4G RF wireless touch remote controls, which can work with our SP63XE, SP52XE etc. series controllers.

2.Features:

- 1. 2.4G wireless remote control technology, with low power consumption, long transmission distance, strong anti-interference ability etc...
- 2. Touch control, high sensitivity, good consistency and reliability.
- 3. Support one-to-many control, a remote control can control multiple controllers.
- 4. Support multi-to-many control, each controller can bind up to 5 remote controls.
- 5. Support unified control and 4-zones control.

3.Functions:


Remote Models



86-Type Panel Models




RC4





Brightness Ring Temperature Ring Color HUE Ring

Different functions according to different models



Long press: Within 20s after the

41,2,3,4

operation

controller is powered on, first turn off

the lights completely, and then long press the button to clear all bound remote controls.

Short press: select specific zone, E.g.

short press 1 first, then press II .

then only zone I will respond to this

Long press: zone setting, within 20s after the controller is powered on, long

press a key 1 ... 4 to set the controller to specific zone.

1 ON Short press: Turn on the light. long press: Within 20s after the controller is powered on, long press to bind/unbind the remote control.

3 ALL Short press:select all zones. long press:Within 20s after the controller is powered on, long

press Att to unset the zones. 5 SPEED 6 MODE

7 MUSIC MODE

4.Technical Parameters: Working Voltage:3V(CR2032) RF frequency: 2.4GHz Remote DiMensions: 135mm*48mm*10mm

5. Cautions:

1. Please match the model of remote control correctly according to the model of controller.

Quiescent Current: 26uA

Remote Range:30M

Panel DiMensions:

86mm*86mm*12mm

- 2. If the LED indicator appears to be unresponsive or flashing chaotically, please replace the battery in time, please do not use inferior batteries.
- 3. Do not touch the touch panel within 2S after installing the new battery.
- 4. Please do not use it in high humidity, high temperature, dusty and high pressure environment.
- 5. Please do not use the remote control in strong electromagnetic interference area, otherwise it will seriously

affect the remote control distance.



Different functions according to different models